


For Model: TEDS840JQ1
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Model: TEDS840JQ1
(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	13	3357011	Screw, 10–16 x 1/2	33	696144	Strike, Door
	LIT3397618	Instructions, Installation	14	692495	Spring, Door (2)	35	695737	Door, Rear
	LIT8528588	Use & Care Guide	15	3394083	Clip, Front Panel (2)	36	3393549	Door, Front
	LIT8528190	Label, Wiring Diagram	16	3392100	Foot, Dryer	37	690270	Handle, Door
Following May Be Purchased				279810	Foot–Optional (Extended Length Package of 2) (Not Included)	38	3406129	Seal & Bearing Assembly
DO-IT-YOURSELF REPAIR MANUALS			17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	39	279393	Terminal Block Kit (For Terminal Block)
	LIT677818	Dryer	18	8530603	Cabinet	40	697776	Screw, 10–32 x 5/8
2	343641	Screw, 10–16 x 1/2	19	98234	Clip, Ground	41	3397659	Block, Terminal
3	693995	Screw, 8–18 x 3/8	20	690363	Lock, Front Top (2)	51	238088	Hinge, Top (2)
5	3396795	Cover, Block	21	695620	Panel, Front	53	3394332	Idler & Slide Assembly
6	342043	Screw, 10–32 x 3/8	23	685203	Clip, Felt Pad (3)	56	8066065	Belt, Drive
7	3396805	Panel, Rear	24	3389441	Catch, Door Assembly	57	348780	Base, Motor
10	3406107	Door Switch Assembly	26	337189	Clip, Hinge (2)	58	3400500	Bolt, 5/16–18 x 3/4
11	697773	Screw, 6–20 x 7/8	27	694091	Screw, 8–18 x 3/8	59	3394341	Pulley, 60 Hz.
			28	8066056	Hinge, R.H.	62	661654	Motor Assembly 60 Hz.
				8066057	Hinge, L.H.	63	660658	Clamp, Motor
			33	696144	Strike, Door	64	3404162	Clamp, Motor (W/Shield)
						67	3390731	Seal, Door
						68	3393008	Screw, 10–16 x 1/2

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: TEDS840JQ1
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: TEDS840JQ1
(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console	12	3978605	Hinge, R.H.	30	357213	Nut, Push-In (2)
2	3401684	Wire, Jumper (Black)		3978606	Hinge, L.H.	31	8299873	Harness, Wiring
3	693995	Screw, Hex Head	13	688983	Screw, 8-18 x 5/8	32	3396029	Wire, Jumper (Temperature)
4	8274437	Cap, End (L.H.)	14	3400859	Screw, Grounding	33	3397269	Connector (Timer)
6	388326	Screw, Console	15	3395683	Connector (Motor)	34	3347243	Connector 6-Circuit
7	694419	Buzzer, Mini	16	8271390	Top	35	94614	Terminal
8	8274434	Cap, End (R.H.)	17	3950759	Knob, Control (2)	39	3398096	Switch, Push-To-Start
9	3399639	Switch, Temperature	18	3394427	Clip-Harness	48	8283182	Timer Knob Assembly
10	349639	Screen, Lint	19	297535	Bumper, Lint Lid	50	3936144	Connector
11	8283378	Cover, Lint Screen	20	3401144	Connector, (PTS Relay)	53	8271418	Bracket, Control
			21	8299782	Timer, 60 Hz.	54	3977932	Panel, Control
			22	3401694	Wire, Jumper (Tan)			
			29	3390646	Screw, Mounting (8-18 x 5/16)			

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

279948 Kit,
Dryer Repair
3406839 Dry Rack

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
350938 Primer, Gray


PAINT, BULK (1 qt.)

799344 White (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: TEDS840JQ1
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: TEDS840JQ1
(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly	11	3405016	Housing, Blower	33	3406124	Bulb
2	487909	Screw, 8-15 x 1/2	12	3398161	Clip	34	3402841	Lens, Drum Light
3	3388703	Washer-Support	13	343641	Screw, 10-16 x 1/2	41	690997	Ring, Tri
4	347139	Seal, Lint Chute	14	3397566	Box, Heater	42	3399506	Shaft, L.H.
5	90767	Screw, 8-18 x 3/8	15	3977767	Thermostat, 221°F (105°C)	43	3399507	Shaft, R.H.
6	696302	Shield, Exhaust	16	3977373	Bracket, Drum Light	44	3397588	Roller, Support
7	3392519	Thermal Fuse	17	3403585	Element, Heater	46	348197	Washer, Support
8	3387134	Thermostat, Internal-Bias	18	8066086	Drum Hole Plug	47	3359452	Nut, 3/8-16
9	3977393	Thermal, Cut-Off (Hi-Limit Thermostat Illus. No.15 Included)	19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)	48	3403413	Bulkhead
10	694089	Wheel, Blower (Includes Illus. No. 22)	20	489463	Screw, 8-18 x 5/8	49	3403634	Socket Assembly
			21	3390647	Screw, 8-18 x 1/2	62	692526	Ring, Bearing (2)
			22	3394196	Seal, Blower	63	97787	Screw, 11-16 x 3/4
						66	3406130	Seal, Rear Drum
						67	695587	Drum Assembly
						68	692490	Baffle, Drum (2)
						69	3976434	Bracket, Support
						70	90296	Clip
						71	3403636	Baffle, Drum (1)
						73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST